



A. Fold and apply to high edge of door bevel and mark center of desired height from the floor.

B. Mark center on door face through guide on template for 2-3/4" (70mm) backset or as desired.

NOTE: NO DOOR PREPARATION IS NEEDED EXCEPT FOR THE 2 PILOT HOLES FOR THE SCREWS SUPPLIED.



6605 Flotilla St.  
 City of Commerce  
 CA 90040 USA  
 Tel: (323) 888-6601  
 FAX: (323) 888-6699  
 Website: cal-royal.com  
 Email: sales@cal-royal.com

ITEM NO.	DESCRIPTION	ANSI	SCALE	UNIT	VERSION
<b>BRI-40</b>	<b>CHELSIE SERIES DUMMY LOCKSET</b>	Grade 3	1 : 1	inches (mm)	ver. 1.0 rev. 01/12
			PAGE 1 OF 1		<b>BY: bteves</b>