



1. SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSHED
2. SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
3. WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED AND TAPPED IN FIELD
4. TOLERANCE ON ALL DIMENSIONS $\pm 1/64"$



7700 PANIC RIM EXIT DEVICE

7700

VERSION DATE
APR - 16 2012
 CAL ROYAL PRODUCTS INC