



LOCATE DRILL & TAP THESE HOLES WHEN APPLYING HARDWARE TO DOOR

4 1/2" FROM FINISHED FLOOR (CENTER LINE OF PUSH)

INSIDE FACE OF DOOR

VERTICAL REFERENCE LINE

② #10-24 TAPPED HOLE (2 REQ'D.)

2 1/8" DIA HOLE THRU DOOR.

℄ OF LATCH BOLT AND HORIZONTAL REFERENCE LINE.

SEE NOTE 3

℄ OF CHASSIS

VERTICAL REFERENCE LINE

- ① NO ADDITIONAL DOOR PREPARATION IS REQUIRED
- ② FOR MOUNTING THE OUTSIDE TRIM
- ③ SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH
- ④ SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
- ⑤ SEE STRIKE TEMPLATE FOR TOP AND BOTTOM STRIKES.
- ⑥ FOR 881 MONITOR STRIKE SEE TEMPLATE 4386.
- ⑦ WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD
- ⑧ TOLERANCE ON ALL DIMENSIONS ±1/64"

2200EO/2220EO

TEMPLATE:	
PANIC RIM TYPE EXIT DEVICE WITH LEVER TRIM	
88.02.05	