



**9800**

- ① NO ADDITIONAL DOOR PREPARATION IS REQUIRED FOR MOUNTING, THE OUTSIDE TRIM
- ② SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH
- ③ SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
- ④ SEE STRIKE TEMPLATE FOR TOP AND BOTTOM STRIKES.
- ⑤ WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD
- ⑥ TOLERANCE ON ALL DIMENSIONS  $\pm 1/64$ "

TEMPLATE:	
PANIC RIM TYPE EXIT DEVICE WITH LEVER TRIM	
日期	01.05.04
姓名	FC-6000