



- Ⓢ NO ADDITIONAL DOOR PREPARATION IS REQUIRED FOR MOUNTING THE OUTSIDE TRIM
- Ⓢ SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH
- Ⓢ SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
- Ⓢ SEE STRIKE TEMPLATE FOR TOP AND BOTTOM STRIKES. FOR 881 MONITOR STRIKE SEE TEMPLATE 4386.
- Ⓢ-Ⓢ WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD
- Ⓢ TOLERANCE ON ALL DIMENSIONS $\pm 1/64$ "

2200EO/2220EO

