



VERTICAL CL

2-3/4"

FOLD AND ALIGN TEMPLATE ON EDGE OF DOOR

FOLD AND ALIGN TEMPLATE ON EDGE OF DOOR

HORIZONTAL CL

DRILL TWO 5/16"
HOLES ON VERTICAL
CENTERLINE FROM
OUTSIDE OF DOOR
1/2" DEEP

2-1/8"
CUTOUT

2-3/4"

3-1/2"

41" FROM FINISHED

TEMPLATE FOR 5000 SERIES
USING 8000L, 8000S AND 8000PAS

FOR WOOD DOORS:
DRILL (4) 3/32" DIA. X 1-1/4"
DEEP PILOT HOLES ON THE
INSIDE OF DOOR
FOR METAL DOORS:
DRILL AND TAP (4) #3/16" HOLES
ON THE INSIDE OF DOOR

7/8"