



- Ⓞ NO ADDITIONAL DOOR PREPARATION IS REQUIRED FOR MOUNTING THE OUTSIDE TRIM
- Ⓢ SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH
- Ⓞ SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
- Ⓞ SEE STRIKE TEMPLATE FOR TOP AND BOTTOM STRIKES FOR MONITOR STRIKE SEE TEMPLATE
- Ⓢ WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD
- Ⓞ TOLERANCE ON ALL DIMENSIONS ±1/64"

F2200 RIM

