



A. Fold and apply to high edge of door bevel and mark center of desired height from the floor.

B. Mark center on door face through guide on template for 2-3/4" (70mm) backset or as desired.

NOTE: NO DOOR PREPARATION IS NEEDED EXCEPT FOR THE 2 PILOT HOLES FOR THE SCREWS SUPPLIED.

| | | | | | | |
|---|---------------|---|---------|----------------------|----------------|--|
|  <p>6605 Flotilla St. City of Commerce CA 90040 USA Tel: (323) 888-6601 FAX: (323) 888-6699 Website: cal-royal.com Email: sales@cal-royal.com</p> | ITEM NO. | DESCRIPTION | ANSI | SCALE | UNIT | VERSION |
| | AUS-40 | CHELSIE SERIES DUMMY LOCKSET | Grade 3 | 1 : 1 PAGE 1 OF 1 | inches (mm) | ver. 1.0 rev. 01/12 BY: bteves |