

A. Fold and apply to high edge of door bevel and mark center of desired height from the floor.

B. Mark center on door face through guide on template for 2-3/4"(70mm) backset or as desired.

NOTE: NO DOOR PREPARATION IS NEEDED EXCEPT FOR THE 2 PILOT HOLES FOR THE SCREWS SUPPLIED.



City of Commerce Tel: (323) 888-6601 FAX: (323) 888-6699 Website: cal-royal.com

MAY-40

ITEM NO.

CHELSIE SERIES DUMMY LOCKSET

DESCRIPTION

Grade 3

ANSI

1:1 PAGE 1 OF 1

SCALE

inches (mm)

UNIT

ver. 1.0 rev. 01/12

VERSION

BY: bteves