

1. MARK DOOR

- A. Fold and apply to high edge of door bevel and mark center of door edge as indicated on template at the desired height from the floor.
- B. Mark center hole on door face through guide on template for 2-3/8" (60mm) or 2-3/4"(70mm) backset.

2. DRILL HOLES

- A. Drill thru door face as marked for lockset. It is recommended that holes be drilled from both sides to presvent splitting. Hole size is 2-1/8"(54mm) for standard installations.
- B. Drill 1"(25mm) hole in center of door edge thru 2-1/8"(54mm) hole for latch. CAUTION: Check center of latch hole for alignment with strike center on jamb to ensure free movement of latch bolt.



6605 Flotilla St. City of Commerce CA 90040 USA Tel: (323) 888-6601 FAX: (323) 888-6699 Website: cal-royal.com Fmail: sales@cal-royal

PRE, RITZ, SIG - 20

ITEM NO.

ASHLEY SERIES
RESIDENTIAL LOCKSET
FUNCTION: PRIVACY

DESCRIPTION

Grade 3

ANSI

1:1 PAGE 1 OF 1

SCALE

inches ver. 1.0 rev. 01/12 (mm)

UNIT

BY: bteves/adg

VERSION