



1. SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSHED
2. SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
3. WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED AND TAPPED IN FIELD
4. TOLERANCE ON ALL DIMENSIONS  $\pm 1/64"$

**F2200 FIRE RATED PANIC RIM EXIT**

**F2200**