

# INSTRUCTIONS FOR CAL-ROYAL THUMBPIECE OUTSIDE TRIM FOR 77EO/7700V SERIES RIM AND VERTICAL ROD EXIT



	77TP-00	77TP-30	77TP-40	77TP-05
	13 function Entrance	15 function Passage	10 function Dummy	04 function Storeroom
	Attach the collar and mortise cylinder to the trim plate with the mortise nut, attach trim to door thru-bolting (2) screws to the chassis & the (2) cup washers and screws at the top & bottom to the door.	Attach trim to the door thru-bolting the (2) screws to the chassis, & (2) cup washers and screws at the top & bottom to the door.	Attach the collar and dummy mortise cylinder to the trim plate with mortise nut. Attach trim to door thru-bolting the (2) screws to the chassis, & (2) cup washers and screws at the top & bottom to the door.	Attach the collar and mortise cylinder to the trim plate with mortise nut, attach trim to door thru-bolting (2) screws to the chassis & the (2) cup washers and screws at the top & bottom to the door.