INSTRUCTIONS FOR CAL-ROYAL THUMBPIECE OUTSIDE TRIM FOR 77EO/7760V SERIES RIM AND VERTICAL ROD EXIT



	77TP-00	77TP-30	77TP-40	77TP-05
Cup washer & screw	Cylinder Nut Mortise Cylinder Blocking Collar	A B B B B B B B B B B B B B B B B B B B	Cylinder Nut Mortise Cylinder Blocking Collar	Cylinder Nut Mortise Cylinde Blocking Collar
Centerline	13 function Entrance	15 function Passage	10 function Dummy	04 function Storeroom
	Attach the collar and mortise cylinder to the trim plate with the mortise nut, attach trim to door thrubolting (2) screws to the chassis & the (2) cup washers and screws at the top & bottom to the door.	Attach trim to the door thrubolting the (2) screws to the chassis, & (2) cup washers and screws at the top & bottom to the door.	Attach the collar and dummy mortise cylinder to the trim plate with mortise nut. Attach trim to door thrubolting the 92) screws to the chassis, & 2() cup washers and screws at the top & bottom to the door.	Attach the collar and mortise cylinder to the trim plate with mortise nut, attach trim to door thrubolting (2) screws to the chassis & the (2) cup washers and screws at the top & bottom to the door.