When EAC device is going to release e-Strike then using Push Button is going to activate door opening when connected to a satandard e-Strike

CARD READER (ACCESS CONTROL)

SPECIAL FUNCTIONS
-ACCESS -ACTIVATE

(GROUND)
(WET-IN 1)

CARD READER SIDE P.B. (ACT 2 + GROUND)

PUSH BUTTON (ACT 1 + GROUND)

DOOR STRIKE (GROUND + COMMON)

Loop/Jumper
12V or 24V + NORMALLY OPEN
VOLTS DEPENDING ON STRIKE REQUIREMENT

Scroll MENU until SPECIAL FUNCTIONS appear. Use UP/DOWN buttons to select the "Access".

Scroll MENU until "IN1 WET" input appears, use UP/DOWN buttons to select "Normally Opened or Closed" status for your device.

CAL-ROYAL PRODUCTS, INC. USA

ITEM NO.	DESCRIPTION :	NOT TO SCALE	UNIT	Prepared By:	DATE	DWG. NO.
8600 Series	OPERATOR WITH 2 CARD READER, PUSH BUTTON AND DOOR STIKE WIRING DIAGRAM	PAGE 1 OF 1	PRIMARY DIMENSION SHOWN IN INCHES, DIMENSIONS IN ( ) ARE MM	BBT / ADG /SC CVL/CMT/AED	12/2022	DCG-1061 / VER: DIAGRAM 2