




INSTALLATION INSTRUCTION

#4400 Series Panic Rim Device




FUNCTION VARIATIONS




TYPES OF INSTALLATION


SINGLE DOOR




DOUBLE DOOR WITH MULLION



DOUBLE DOOR WITHOUT MULLION



PARTS



A

FIGURE A





FIGURE B



1. REMOVE BOLTS, SCREWS AND SPRING - FIGURE A, STEPS 1 THROUGH 4
2. INTERCHANGE LATCH AND PLATE
3. REINSTALL BOLTS, SCREWS AND SPRING - FIGURE B, STEPS 1 THROUGH 4


F

MOUNT END CASE CHASSIS ON DOOR AND ATTACH END CASE COVER TO CHASSIS




G

ASSEMBLE AND SECURE CROSS BAR TO ARMS



B


1. MARK VERTICAL CENTERLINE ON DOOR ACCORDING TO TYPE OF INSTALLATION AND STRIKE USED (SEE "TYPES OF INSTALLATION")



H


MOUNT STRIKE IN CENTRAL POSITION TO ALLOW FOR FUTURE ADJUSTMENTS

INSTRUCTION FOR APPLYING OUTSIDE RIM



C


DRILL AND CUT HOLES AS DIRECTED ON TEMPLATE



D

ATTACH OUTSIDE TRIM WHEN USED


REMOVE COVER FROM MAIN CASE CHASSIS AND MOUNT CHASSIS TO DOOR



E

ATTACH MAIN CASE COVER TO CHASSIS WITH FOUR MOUNTING SCREWS

NOTE: TOP GRIP SCREW GOES THRU CHASSIS INTO GRIP



THUMB PIECE

