## **SETTING UP GATEWAY (BLEGW-99)**




\*\*When setting up lock with gateway, make sure that the BLEGW-99 is plugged in to a power source, within bluetooth range of the lock and within wi-fi signal range.



 On the admin phone where the lock is registered, go to LOCKS on K3 app




Swipe left on the name of the lock you are trying to pair with the gateway and tap INFO




3. Scroll down and tap GATEWAY MANAGEMENT



4. Tap **SET UP NEW GATEWAY** 





 Set a name for your gateway, fill in the SSID and password for your wi-fi accordingly and tap SYNC TO LOCK




6. Follow the instructions that pop up on your phone. (There is a tool inside the BLEGW-99 packaging that can be used to press the setup button).









7. Wait for the gateway to finish pairing with the lock.



Once the gateway is set up, you will see all the information, under the lock it was paired with.