





# FOR 9800/9860V SERIES RIM & VERTICAL ROD DEVICE

98TP-00	98TP-30	98TP-40	98TP-05
 <p data-bbox="491 976 726 1117"><b>Lockable Thumbpiece Trim</b> Key locks &amp; Unlocks lever</p>	 <p data-bbox="894 976 1188 1044"><b>No Cylinder Trim Always Operable</b></p>	 <p data-bbox="1245 976 1539 1084"><b>Pull when push bar locked down. Dummy Thumbpiece Trim</b></p>	 <p data-bbox="1629 976 1959 1117"><b>Key unlock Thumbpiece. Key remains in cylinder unless locked. Cylinder Thumbpiece trim.</b></p>
<p data-bbox="569 1138 730 1206"><b>13 Function Entrance</b></p>	<p data-bbox="961 1138 1123 1206"><b>15 Function Passage</b></p>	<p data-bbox="1325 1138 1486 1206"><b>10 Function Dummy</b></p>	<p data-bbox="1703 1138 1864 1206"><b>04 Function Storeroom</b></p>
<p data-bbox="520 1230 756 1450">ATTACH THE COLLAR AND MORTISE CYLINDER TO THE TRIM PLATE WITH THE MORTISE NUT. ATTACH TRIM TO DOOR THRU BOLTING (2) SCREWS TO THE CHASSIS &amp; THE (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>	<p data-bbox="921 1230 1136 1385">ATTACH TRIM TO DOOR THRU BOLTING THE (2) SCREWS TO THE CHASSIS &amp; (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>	<p data-bbox="1297 1230 1512 1385">ATTACH TRIM TO DOOR THRU BOLTING THE (2) SCREWS TO THE CHASSIS &amp; (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>	<p data-bbox="1661 1230 1896 1450">ATTACH THE COLLAR AND MORTISE CYLINDER TO THE TRIM PLATE WITH THE MORTISE NUT. ATTACH TRIM TO DOOR THRU BOLTING (2) SCREWS TO THE CHASSIS &amp; THE (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>

