

INSTALLATION INSTRUCTION FOR PANIC VERTICAL ROD EXIT DEVICE.



1. MARK VERTICAL AND HORIZONTAL REFERENCE LINE ON DOOR.


DETERMINE BACKSET TO LOCATE VERICAL REFERENCE LINE.

- 1. IF LOCK STILE IS 4 1/2" WIDE OR WIDER. BACKSET IS 2 3/4".
- 2. IF LOCK STILE IS LESS THAN 4 1/2" WIDE, BVACKSET IS HALF OF THE EXPOSED WIDTH OF LOCK STILE.




2. PREPARE DOOR


TAPE TEMPLATE ON INSIDE OF DOOR ALONG REFERENCE LINE. SPOT AND DRILL HOLE.



3. APPLY TRIM+CHASIS




4. ATTACH TOP AND BOTTOM CHASIS




5. APPLY RAIL ASSEMBLE

- 1. CHECK THE SIZE OF DEVICE, IF CUTTING TO LENGTH IS REQUIRED.
- DETERTMINE CUT OFF LENGTH "X" BY SUBTRACTING 1 3/4" FROM "Y". MARK CUT OFF POINT ON MOUNTING RAIL.



3. DREPRESS ARM INTO RAIL OPENING AND SLIDE RAIL ONTO CHASIS. LEVEL RAIL AND FASSTEN CHASIS AND MOUNTING TIGHT AGAINST RAIL



6. APPLY COVER

CHECK FINAL OPERATION OF DEVICE AND ADJUST THEN FASTEN COVERS.

