

1/2" (12.7mm) COMMERCIAL SADDLE THRESHOLD

1/2"H x 5"W x 36"L

12.7 mm x 127 mm x 914.4 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.

4. Seal both ends and along the sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.



MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



FINISH: DARK BRONZE ANODIZED ALUMINUM

1/2" (12.7mm) COMMERCIAL SADDLE THRESHOLD

1/2"H x 5"W x 36"L

12.7 mm x 127 mm x 914.4 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

 Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
Seal both ends and along the sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.





1/2" (12.7mm) COMMERCIAL SADDLE THRESHOLD

1/2"H x 5"W x 48"L

12.7 mm x 127 mm x 1219.2 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.

4. Seal both ends and along the sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.



MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



FINISH: DARK BRONZE ANODIZED ALUMINUM

1/2" (12.7mm) Commercial Saddle Threshold

1/2"H x 5"W x 48"L

12.7 mm x 127 mm x 1219.2 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

 Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
Seal both ends and along the sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.





1/2" (12.7mm) COMMERCIAL SADDLE THRESHOLD

1/2"H x 5"W x 72"L

12.7 mm x 127 mm x 1828.8 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

 Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
Seal both ends and along the

sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.



MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



FINISH: DARK BRONZE ANODIZED ALUMINUM

1/2" (12.7mm) COMMERCIAL SADDLE THRESHOLD

1/2"H x 5"W x 72"L

12.7 mm x 127 mm x 1828.8 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

 Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
Seal both ends and along the sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.





1/2" (12.7mm) COMMERCIAL SADDLE THRESHOLD

1/2"H x 5"W x 96"L

12.7 mm x 127 mm x 2438.4 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

3. Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.

4. Seal both ends and along the sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.



MATERIAL FOR USE IN LISTED STEEL FRAMES AND CLASSIFIED HOLLOW METAL STEEL COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 3 HOURS, WOOD COMPOSITE TYPE FIRE DOORS ARE RATED UP TO AND INCLUDING 1-1/2 HOURS, AND WOOD CORE FIRE DOORS ARE RATED 20 MINUTES WITHOUT HOSE STREAM.



FINISH: DARK BRONZE ANODIZED ALUMINUM

1/2" (12.7mm) Commercial Saddle Threshold

1/2"H x 5"W x 96"L

12.7 mm x 127 mm x 2438.4 mm

INSTALLATION INSTRUCTIONS

 Measure width at the bottom of the frame and cut the threshold to exact full width of the opening.
If necessary trim and notch the threshold ends to accommodate the side jamb stops.

 Mark and drill pilot holes through the pre-drilled holes in the threshold and fasten with screws provided.
Seal both ends and along the sides of the threshold.

5. Operate the door multiple times to ensure proper adjustment so as not to prevent the door from selfclosing and latching.

